CAEN C-139 CAMAC INTERFACE

INTRODUCTION

The model C 139 is the CAMAC Interface for the CAEN SY 127 and SY 227 High Voltage Systems.

It allows the user to carry out the full monitoring and control of a HV system from any computer connected to CAMAC. In this way, for each application, a dedicated software can be developed using high-level languages and a library of standard ESONE CAMAC routines.

Appropriate error codes are returned for any operation performed on the system.

Up to 100 crates daisy-chain connected, between the SY 227 and the SY 127, can be controlled by a single C 139 unit. The module is one CAMAC unit wide.

Information is exchanged between the C 139 and the SY 127 or SY 227 systems via a HIGH VOLTAGE CAENET serial link, which uses a 50 Ω coaxial cable as a physical medium.

1. SYSTEM OVERVIEW

Two basic kinds of actions can be thought of in connection with the monitoring and the control of a HV system, i.e. **setting a parameter's value** and **reading it out.**

Both actions can be expanded in a sequence of operations, where each operation is performed via a specific CAMAC function on the C.139 interface, with the appropriate Subaddress and Data fields.

Only three ESONE standard CAMAC calls are needed to fulfill the task.

Each time the Write Lines 1 - 16 and Read Lines 1 - 16 are mentioned, they refer to bits 0 - 15 and vice-versa.

1.1 SET PARAMETER VALUE sequence

This is expanded in:

SELECT TARGET
READ ERROR FLAG
WRITE DATA
READ ERROR FLAG

a) **SELECT TARGET** is intended to specify which Channel, or group of Channels, or block of HV parameters are the target of the subsequent WRITE DATA operation (which actually performs the setting of the parameter's value).

SELECT TARGET is needed only when a new target has to be specified, i.e. in case of consecutive actions performed on the same target (e.g.changing several parameters of the same HV Channel) only one target selection is required at the beginning.

SELECT TARGET is performed via an F17 function.

Possible targets are a single HV Channel (HV parameters which can actually be set through CAMAC are detailed under the WRITE DATA specifications below), Group of Channels (same remark), a set of global Crate Protection bits, and the set of parameters describing the status of the Streamer-tubes-conditioning process (they are read-only parameters).

It is worth noticing that only one Crate at a time can be acted upon (its number being given in the SELECT TARGET Data field).

b) **WRITE DATA** performs the setting of the parameter, whose new value is in the CAMAC Write lines.

Only a limited set of parameters (detailed below) can be set through CAMAC for a single Channel, or in parallel for a group of Channels. For some parameterrs even (as for the Channel Status), only few specific bits can be modified.

WRITE DATA is performed via a F16 function.

c) **READ ERROR FLAG** can be performed at any time to find out the outcome of a previous operation.

It consists of an F0 function.

A single negative word read out corresponds to an error condition. (see (a) note 2.4)

Though optional, the use of READ ERROR FLAG is strongly recommended when writing high-level self-contained software.

1.2 READ PARAMETER VALUE sequence

This is expanded in:

SELECT TARGET
READ ERROR FLAG
START READOUT
READ VALUE(S)

a) **SELECT TARGET** has the same form, meaning and limitations as in the SET PARAMETER VALUE sequence.

b) **START READOUT** is needed, in case of a READ sequence, in order to steer the readout on a specific subset of the vast parameters' set: thus, the readout of the (one or several) resulting parameter values can be performed most effectively with a Q-STOP read operation (see the READ VALUE below), without any further Subaddress specification.

START READOUT is performed via an F17 function.

c) **READ VALUE(S)** reads out (in Q-STOP mode) a block of data, one or more words depending on which target was specified in the SELECT TARGET and on the subset chosen in the previous START READOUT.

READ VALUE(S) is performed via a F0 function.

A single negative word read out corresponds to an error condition occurred during the previous operation (which had to be a START READOUT).

2. *CAMAC FUNCTIONS (referring to the SY 127 system)*

The meaning of the Subaddress and Data fields for the CAMAC functions is detailed. Refer to the SY 127 System Manual for further information and for the meaning of the Channels' parameters.

2.1 *SELECT TARGET*

F17 in which the Subaddress is ignored, while bits 0-7 of the Write Lines select the desired target and bits 8-15 specify the number (between 0 and 99) of a Crate in the SY 127 System.

Crate numbers 100 to 255 are reserved to the System. An invalid crate number at this stage is immediately reported as an error code -1.

The value of the lower byte of the Write lines is interpreted as follows:

0-39 gives the **number of the Channel** selected (40 Channels per Crate max.).

40-48 selects a block of parameters relative to the Streamer-tubes-conditioning process, specifically:

40	selects one of the values of the **Voltages** (V0-V15)
41	selects one of the values of the **Currents** (ID-I15)
42	selects one of the values of **Time-High** (TH0-TH15)
43	selects one of the values of **Time-Low** (TL0-TL15)
44	selects the **Maximum Width Time** of a conditioning step
45	selects the **Ramp-up** rate
46	selects the **Ramp -down** rate
47	selects the set of three possible commands: **Start** (BIT 0), **Stop** (BIT 1), **Pause** (BIT 2)
48	selects the **Total Width Time** of the conditioning process

Warning: these parameters can only be read out, and not written on. *Any subsequent attempt to write on them via a WRITE DATA will result in an error code -48.*

For targets 40-43, the subaddress in the Start_Readout operation (see below) selects which one of the corresponding 16 values has to be read.

50-57 selects a **Global Absolute Group** as follows:

50	Group ALL
51	Group A
52	Group B
53	Group C
54	Group D
55	Group E
56	Group F
57	Group G

60-67 selects a **Global Relative Group** as follows:

60	Group ALL
61	Group A
62	Group B
63	Group C
64	Group D
65	Group E
66	Group F
67	Group G

70 selects the **Protection bits**

2.2 WRITE DATA

F16 where the value of the Subaddress selects the parameter and the Write Lines contain the data to be written.

a) For a **Single Channel selection** (Target = 0-39 in the Select Target operation) only subaddresses 0 to 8 are allowed.

Use of a subaddress > 8 will result in the error -5.

The meaning of the subaddresses is:

0	selects the setting of **V0**
1	selects the setting of **V1**
2	selects the setting of **I0**
3	selects the setting of **I1**
4	selects the setting of the **Ramp-up** rate
5	selects the setting of the **Ramp-down** rate
6	selects the setting of the **Trip**
7	selects the setting of the **Status bits*** (see note over page)
8	selects the setting of the **Channel to Group assignment bits**** (see note over page)

b) For a **Global Absolute Group selection** (Target = 50-57), only the subadresses 0-7 of the above list are allowed.

Use of subaddress 8 will result in the error -9.
Use of a subaddress > 8 will result in the error -5.

c) For a **Global Relative Group selection** (Target = 60-67), only the subaddresses 0-6 of the above list are allowed.

Use of subaddresses 7 and 8 will result in the error -11.
Use of a subaddress > 8 will result in the error -5.

d) For a **Protection Bits** selection *(Target = 70)*, the subaddress is ignored, and only the first 4 bits of the data field are used*** (see note over page).

Any attempt to write a bit which is different from 0 - 3 it will result in error -12.

IMPORTANT:

The setting of the Write Lines depends on the HV module on which one has to act as well as on the operation to be performed. Refer to Chapter 2.5 for details.

NOTES:

***) Status Bits**

The only Status bit which can be changed via CAMAC is bit 0, the ON / OFF bit. If a 1 is written on bit 0, the Channel is turned ON, if a 0 is written, the Channel is turned OFF.

Any attempt to write on a Status bit different from bit 0 will result in error -4.

***\) Channel to Group assignment Bits**

A mask on the Write lines is used to describe which Groups a Channel will belong to (the Channel to Group assignment bits): **bit 0** represents **Group ALL**, **bit 1 Group A**, and so on to **bit 7** which represents **Group G.** If one of these bits is set to 1, the Channel will belong to the corresponding Group, if it is set to 0 the Channel will be discarded from that Group.

***Care must be taken**, before giving such a command, to read the current status, in order to find out which Groups a Channel belongs to.*

*****) Protection Bits**

If a bit is set to 1, the corresponding Protection is enabled, if it is set to 0, the Protection is disabled.

***Care must be taken**, when modifying the Protections Bits, to act only on the relevant ones, leaving the others unchanged.*

The meaning of these 4 bits is:

bit **0 Power ON**
bit **1 Password enable**
bit **2 Keyboard enable**
bit **3 Clear Alarm**

Note on the Alarm bit:
If during a READ operation this bit is set to 1, then an Alarm condition has taken place, which could be due to a Trip-off, an Over-voltage or an Under voltage status of the channel.
An Alarm condition can be reset (Clear Alarm operation) writing a 1 on bit 3: then the bit should toggle to zero if it was set, or stay zero if no alarm condition was present.
***Warning:** if, following a Clear Alarm operation, bit 3 is still set to 1, then the Alarm condition persists, and it is caused either by an Over-voltage or by an Under-voltage status of the HV channel.*

2.3 START READOUT

F17 in which the Subaddress selects the desired parameter and bits 8-15 of the Write Lines must all be set to 1.

a) For a **Single Channel selection** (Target = 0-39) the Subaddress meaning is:

- **0** selects the readout of **V0**
- **1** selects the readout of **V1**
- **2** selects the readout of **I0**
- **3** selects the readout of **I1**
- **4** selects the readout of the **Ramp-up** rate
- **5** selects the readout of the **Ramp-down** rate
- **6** selects the readout of the **Trip** setting
- **7** selects the readout of the **Channel Status**
- **8** selects the readout of the **Channel to Group assignment bits**
- **9** selects the readout of VMON
- **10** selects the readout of IMON
- **11** selects the readout of the **Phase** of the **Streamer tubes conditioning** process (see note * below)
- **12** selects the readout of the **Time** of the **Streamer tubes conditioning** process (see note * below)
- **13** selects the readout of the **Channel Type**
- **14** **invalid**
- **15** selects the readout of **all the parameters** in a block (see note ** below)

Notes:

*) ***The Streamer Tubes Conditioning can only take place on channels belonging to Group A.***
Thus the values read back with subaddresses 11 and 12, when working on a channel belonging to a Group different from Group A, are meaningless.

**) The order in which the parameters are read is:
V0, V1, I0, I1, Ramp-up rate, Ramp-down rate, Trip, Channel Status, Channel to Group assignment, VMON, IMON, Conditioning Process Phase, Conditioning Process Time, Channel Type

Here too, the Conditioning Process Phase and Time are meaningful only if the channel belongs to Group A.

b) For a **Global Absolute or Relative Group selection,** the same meanings apply to the subaddresses as for the single channel selection, with the restrictions mentioned for subaddresses 11-12, valid only on Group A.

c) In a **Streamer tubes conditioning process selection:**

- **for targets 40-43,** the subaddress (0-15) selects one of the 16 values of the associated parameters (e.g. for Target = 40, Subaddress = 3 selects V3).
- **for targets 44-48,** the subaddress is ignored.

d) For a **Protection Bits readout selection** the subaddress is ignored.

2.4 READ VALUE(S)

F0, in which the Subaddress is ignored, and on the Read lines the desired data are presented.

F0 must be repeated until a Q=1 response is obtained: the readout is over when Q=0.

a) **Data format for Group Selection:**

If a Group (Global Absolute or Global Relative) is selected, the block of data begins with 3 "pattern" words describing which Channels belong to the Group.

In the first 2 words, and in the lower byte of the third word, each bit represents a Channel of the Crate, the Least Significant Bit of the first word representing Channel 0 and so on to Channel 39. After these initial "pattern" words, as many words follow as the number of Channels belonging to that Group; they contain the value of the selected parameter for the corresponding Channel, i.e. the first word refers to the Channel corresponding to the first bit set to 1 in the 3 initial "pattern" words, and so on.. (NOTE: The first word could be a negative word. In this case it could be an error code).

Example of read-out of V0 for Global Absolute Group B in Crate 0:

SELECT TARGET = F17, 0, 52(decimal)	A = 0	ignored
	Bit 0 - 7 = 52	Global Abs. group B
	Bit 8 - 15 = 0	Crate 0
START READOUT = F17,0,Fxx (octal)	A=0	selects V0
	Bit 0 - 7 = 0	ignored
	Bit 8 - 15 = 255	all one's

READ VALUES = F0, 0, R-LINES, Q, where:

Q = 1 R-LINES = 5	==>	channels 0 and 2 belong to theGroup
Q = 1 R-LINES = 0		
Q = 1 R-LINES = 1	==>	also channel 32 belongs to Group
Q = 1 R-LINES = 1700	==>	V0-voltage of channel 0 = 1700 Volts
Q = 1 R-LINES = 2000	==>	V0-voltage of channel 2 = 2000 Volts
Q = 1 R-LINES = 0	==>	V0-voltage of channel 32 = 0 Volts
Q = 0	==>	READ-OUT OVER

b) **Channel Status word's bit pattern:**

bit	**0 OFF**	(if set to one, channel is OFF, and bit 2 goes to zero)
bit	**1 Trip**	(if set to one, channel was switched off because of Trip)
bit	**2 ON**	(if set to one, channel is ON, and bit 0 goes to zero)
bit	**3 Over-Voltage**	(if set to one, channel is in OVV at time of reading)
bit	**4 Under-Voltage**	(if set to one, channel is in UNV at time of reading)
bit	**5 Over-Current**	(if set to one, channel is in OVC at time of reading)
bit	**6 Ramp-up**	(if set to one, channel is undergoing a R-UP phase)
bit	**7 Ramp-down**	(if set to one, channel is undergoing a R-DW phase)

c) **Channel to Group assignment word's bit pattern:**

bit **0 set to 1** means that the Channel belongs to **Group ALL**, bit **1 set to 1** means that the Channel belongs to **Group A** and so on up to bit 7 which corresponds to **Group G.**

d) **Channel Type word's bit pattern:**

Positive Channel	bit 7	**OFF**			
Negative Channel	bit 7	**ON**			
800 Volts - 500 µA	bits 1, 2	**ON**			
2 KVolts - 5 mA	bit **0**	**ON**	or bits	**1,2,3**	**ON**
3 KVolts - 3 mA	bit **1**	**ON**	or bits	**0,1,2,3**	**ON**
4 KVolts - 2 mA	bits **0, 1**	**ON**	or bits	**2, 3**	**ON**
6 KVolts - 1 mA	bits **0, 2**	**ON**	or bits	**2, 3**	**ON**
8 KVolts - 500 µA	bit **2**	**ON**			
8 KVolts - 200 µA	bits **0, 1, 2**	**ON**	or bits	**1, 4**	**ON**
6 KVolts - 200 µA	bit **3**	**ON**			
4 KVolts - 200 µA	bits **0, 1, 3**	**ON**			
2 KVolts - 200 µA	bits **1, 3**	**ON**			
200 Volts - 200 µA	bits **0, 3**	**ON**			
Special Module	bits **0, 2, 3**	**ON**			
800 Volts - 200 µA	bits **4**	**ON**			
10 KVolts - 1mA	bits **0, 1, 4**	**ON**			
10 KVolts - 200 µA	bits **1, 2, 4**	**ON**			
15 KVolts - 200 µA	bits **0, 1, 2, 4**	**ON**			
15 KVolts - 1 mA	bits **3, 4**	**ON**			
I/O - Module	bits **0, 1, 2, 3, 4**	**ON**			

e) **Protection Status word's bit pattern:**

bit	**0**	**Power ON**
bit	**1**	**Password enabled**
bit	**2**	**Keyboard enabled**
bit	**3**	**Alarm ***
bit	**4**	**if 0, V0 active - if 1, V1 active**
bit	**5**	**if 0, I0 active - if 1, I1 active**
bit	**6**	**Alarm ***
bit	**7**	**if 0, HV-ENABLE is OFF - if 1, HV-ENABLE is ON**

* They both have the same meaning: Alarm signal for OVV, UNV, TRIP in any one of the channels of the system SY 127 which has been called (see note in the Alarm bit p.8).

f) **Streamer tubes conditioning phase: bit pattern**

bit 0-3	sequential number of the phase (0 to 15 max)
bit 5	if = 1 , means that the conditioning process was terminated by time-out occurrence
bit 6	if = 1 , means that the channel is undergoing a "recovery" at zero voltage (this lasts Time-Low(N) seconds, where N = phase number as given by bits 0-3)
bit 7	if = 1 , means that the conditioning process is active

IMPORTANT:

The decoding of the Read Lines depends on the HV module on which one has to act as well as on the operation to be performed. Refer to Chapter 2.5 for details.

2.5 READ AND WRITE LINES INTERPRETATION (SY 127)

The setting of the Write Lines (W.L.), and conversely the values implied by the Read Lines (R.L.), depend on the characteristics of the specific HV module which is used and on the "target" which has been specified with the "SELECT TARGET" operation (i.e Group of channels or Single Channel - refer to Chapter 2.1 for details).

In particular, **for the Write Lines only**, bit 14 of the data field has a specific meaning (note that no H.V. value can be high enough to affect this bit).

bit 14 ON means that the H.V. value has to be divided by 10 (i.e you set a value in tenth of a Volt or in hundredths of a Volt instead of in Volts.)

bit 15 is the sign bit: when set to 1, the W.L. 0 to 13 , representing the H.V. value, are coded in binary twos-complement.

***Caution:** bit 14 is not affected by the value of bit 15, i.e. it is never complemented to 2.*

2.5.1 HV and RAMP setting and read-out

a) The following HV modules feature a 1/10 Volt resolution:

200 V - 200 µA
800 V - 500 µA

For these modules, the Read Lines always report a value in tenth of a Volt, irrespecive of the bit 14 setting and of the target selected.
For the Write Lines, the voltage unit implied depends on the target as well as on the setting of bit 14, according to the following table:

a.1) Single Channel Target Selection

bit 14 OFF **unit = 1/10 Volt**
(e.g. W.L. = 32 ==> V0 = 3.2 Volts
V0 = 3.2 Volts ==> R.L. = 32)

bit 14 ON **unit = 1/100 Volt**
(the H.V. value set is rounded to the highest 1/10 V value below,
e.g. W.L. = 64 ==> V0 = 0.6 Volts
V0 = 0.6 Volts ==> R.L. = 6)

a.2) Group (Absolute or Relative) Target Selection

bit 14 OFF **unit = 1 Volt**
(e.g. W.L. = 17 ==> V0 = 17 Volts
V0 = 17 Volts ==> R.L = 170)

bit 14 ON **unit = 1/10 Volt**
(e.g. W.L. = 17 ==> V0 = 1.7 Volts
V0 = 1.7 Volts ==> R.L. = 17)

b) The following HV modules feature a 1/2 Volt resolution:

2 KV - 200 µA
2 KV - 3 mA

For these modules, the Read Lines always report a value in half-volts, i.e. the actual voltage in Volts is the number encoded in the R.L. divided by 2.

The conversion table for the Write Lines follows:

b.1) Single Channel Target Selection

bit 14 OFF **unit = 1/2 Volt**
(e.g. W.L. = 16 ==> V0 = 8 Volts
V0 = 8 Volts ==> R.L. = 16)

bit 14 ON **unit = 1/20 Volt**
(the H.V. value set is rounded to the highest 1/2 V value below,
e.g. W.L. = 22 ==> V0 = 1.0 Volts
V0 = 1.0 Volts ==> R.L. = 2
W.L. = 17 ==> V0 = 0.5 Volts
V0 = 0.5 Volts ==> R.L. = 1)

b.2) Group (Absolute or Relative) Target Selection

bit 14 OFF **unit = 1 Volt**
(e.g. W.L. = 100 ==> V0 = 100 Volts
V0 = 100 Volts==> R.L. = 200)

bit 14 ON **unit = 1/10 Volt**
(the H.V. value set is rounded to the highest 1/2 V value below,
e.g. W.L = 32 ==> V0 = 3.0 Volts
V0 = 3.0 Volts ==> R.L. = 6
W.L. = 37 ==> V0 = 3.5 Volts
V0 = 3.5 Volts ==> R.L. = 7)

Note:
when selected in an Absolute Group, the Voltage resolution of the 2 KV-200µA modules depends on the H.V. value itself, namely:

for 0 V < H.V. < 1639.0 V resolution = 1/2 Volt
for 1638 V < H.V. < 2000.0 V resolution = 1 Volt

In the range 1638 - 2000 Volts, a 1/2 Volt resolution can still be obtained if the modules are selected as a Relative Group.

c) The following HV modules feature a one-Volt resolution:

8 KV - 200 µA
6 KV - 200 µA
4 KV - 200 µA

8 KV - 500µA
6 KV - 1 mA
3/4 KV 2/3 mA

For these modules, the value read in the Read Lines has always to be interpreted as Volts.

For the Write Lines, there is no distinction due to the target selection mode, but only a dependence on the setting of bit 14, according to the following table:

bit 14 OFF **unit = 1 Volt**
(e.g. W.L. = 50 ==> V0 = 50 Volts
V0 = 50 Volts ==> R.L. = 50)

bit 14 ON **unit = 1/10 Volt**
(the H.V. value set is rounded to the highest integer value below,
e.g. W.L. = 105 ==> V0 = 10 Volts
V0 = 1- Volts ==> R.L. = 10)

2.5.2 SETTING and READ-OUT of the current

The HV modules with a 1/10 of a μA current resolution follow the same rules as stated for the modules with a 1/10 voltage resolution and those with 1 μA follow the rules for 1 Volt.

3. CAMAC FUNCTIONS (referring to the SY 227 system)

The meaning of the Subaddress and Data fields for the CAMAC functions is detailed. Refer to the SY 227 System Manual for further information and for the meaning of the Channels' parameters.

3.1 SELECT TARGET

F17 in which the Subaddress is ignored, while bits 0-7 of the Write Lines select the desired target and bits 8-15 specify the number (between 0 and 99) of a Crate in the SY 227 (or SY 127) System.

Crate numbers 100 to 255 are reserved to the System. An invalid crate number at this stage is immediately reported as an error code -1.

The value of the lower byte of the Write lines is interpreted as follows:

0-31 gives the number of channels selected on each distribution board for single channel operations;

50 for operations common to all the channels on the selected slot;

70 for operations on the system protection bits (the protection reading requires no subaddress).

3.2 WRITE DATA

F16 where the value of the Subaddress selects the parameter and the Write Lines contain the data to be written.

a) For a **single channel selection** (Target = 0 31 in the select target operation) only subaddresses 0 and 3 are allowed.

The meaning of the subaddresses is the following:

0 Slot selection (see note (o) 3.5)
3 IMAX (see note (ii) 3.5)

Use of subaddresses different from 0 and 3 give an error (see Error Codes).

b) For operations referring to **all the channels on the selected slot** (Target = 50); only subaddresses 0, 3, 5 and 6 are allowed.

The meaning of the subaddresses is the following:

0 Slot selection (see note (o) 3.5)
2 Zero Current Set (see note (x) 3.5)
3 IMAX (see note (ii) 3.5)
5 ON/OFF HV (see note (iii) 3.5)
6 EN/DIS pulse test (see note (iv) 3.5)

Use of subaddresses different from 0, 3 , 5 and 6 give an error (see Error Codes).

c) For operation referring to the Protection Bit selection (Target = 70). Subaddress is ignored, and only the first bit of the data field is used (see note (v) 3.5).

Any attempt to write a bit different from 0 gives an error (see Error Codes).

3.3 START READOUT

F17 in which the subaddress selectos the desired parameter and bits 8-15 of the Write Lines must all be set to 1.

a) For a **single channel selection** (target = 0 - 31).

The subaddress meaning is:

0 Slot number (see note(o) 3.5)
1 VMON (see note(vi) 3.5)
2 IMON (see note (ii) 3.5)
3 IMAX (see note (ii) 3.5)
7 Status (see note (viii) 3.5)
15 selects the readout of **all the parameters** in a block*

* The order in which the parameters are read is : Slot Number, VMON, IMON, IMAX, STATUS.

Use of different subaddresses from those above will give error (see Error Codes).

b) For operations referring to **all the channels on the selected slot** (target = 50)

(see 3.4 Read Values).

The subaddress meaning is:

0 HV boards present in the crate (see note (i) 3.5)
1 VMON (see note (vi) 3.5)
2 IMON (see note (ii) 3.5)
3 IMAX (see note (ii) 3.5)
4 HV IN status (see note (vii) 3.5)
5 HV ON/OFF (see note (iii) 3.5)
6 Pulse test (see note (iv) 3.5)
7 Status (see note (viii) 3.5)
8 Number of channels on the slot
9 Current resolution (see 3.4)
10 Full scale current (see note (ii) 3.5)
11 Voltage resolution (see 3.4)
12 VMAX (see note (vi) 3.5)
13 HV IN polarity (see note (ix) 3.5)
15 All parameters*.

* The order in which the parameter are read is : HV Board, VMON, IMON, IMAX, HV IN status, HV ON/OFF, Pulse Test, STATUS, Number of channels, Current resolution, Full Scale, Voltage resolution, VMAX, HV IN polarity.

Use of different subaddresses from those above will give error (see Error Codes).

c) For operation referring to the Protection Bit selection (Target = 70). Subaddress is ignored, and only the first bit of the data field is used (see previous (v) note).

3.4 READ VALUES

F0, in which the Subaddress is ignored, and on the Read lines the desired data are presented.

F0 must be repeated until a Q=1 response is obtained: the readout is over when Q=0.

Data format for **all channels on the selected slot:**

If all channels are selected, the block of data begins with 1 "pattern" word which is always the slot number.

After these initial "pattern" words, as many words follow according to the selected parameter:

VMON, IMON, IMAX and Status have as many pattern words as channels on the slots;

Current resolution, Voltage resolution : have two pattern words:
the first pattern is the value, the second is the unit measurement in ASCII code (in the least significant 8 bits the A(amps) or V(voltage) character is read, in the most significant 8 bits you can read 'n' (nano) or 'u' (micro) or 'm' (milli) or Blank;

All the other parameters have only one pattern word.

3.5 READ and WRITE LINES Interpretation (SY 227)

Notes:

(o) In the slot selection the Write line or Read line mean the following:

Read or Write line = 0 slot 1
Read or Write line = 1 slot 2
Read or Write line = 2 slot 3
Read or Write line = 3 slot 4

Use of different bit in the write line gives an error. (see Error Code)

(i) In the HV board selection the Read lines when equal to one have the following meaning:

Bit 0 = slot 1 present;
Bit 1 = slot 2 present;
Bit 2 = slot 3 present;
Bit 3 = slot 4 present.

The number of the slots runs from high to low.

(ii) The data to be written or read are the absolute value divided by the current resolution of the board.
e.g. If you wish to set the IMAX value equal to 800 nA in a board which has a current resolution of 5 nA , the data will be equal to 800 ÷ 5 = 160.

Use of different bit in the write line gives an error. (see Error Code)

(iii) H.V. ON/OFF:
In write data only bit 0 is significant.
In read value bit 0 and bit 1 are significant.

Bit 0 = 1 (H.V. Relay ON)
Bit 0 = 0 (H.V. Relay OFF)
Bit 1 = 1 (switch ON) *
Bit 1 = 0 (switch OFF)

Any attempt to write a bit different from 0 gives an error. (see Error Codes).

* It is possible to recognize the change of the status of the manual switch only if there is High Voltage in the input.

WARNING: It is possible to turn on the Relay only if the input does not have High Voltage.

Any attempt to switch on the Relay in this case gives an error (see Error Codes).

(iv) In the EN/DIS pulse test only bit 0 is significant.
Bit 0 = 1 (Pulse Test Enable)
Bit 0 = 0 (Pulse Test Disable)

Use of different bit in the write line gives an error. (see Error Code)

(v) In changing the Protection Bit selection, subaddress is ignored, and only the first bit of the data field is used.
Bit 0 = 1 (Password Enable)
Bit 0 = 0 (Password Disable)

Use of different bit in the write line gives an error. (see Error Code)

(vi) The read value is absolute.

(vii) In the HV IN status selection the read line means the following:
Read line = 0: no HV present in the input .
Read line = 1: positive HV in the input.
Read line = 2: negative HV in the input.

(viii) In the STATUS selection the Read lines bit 0, bit 1, bit 2, bit 3 and bit 8 when equal to one have the following meaning:
Bit 0 = 1 (fixed)
Bit 1 = OVC (overcurrent)
Bit 2 = OFS (over full scale)
Bit 3 = OMV (over max voltage)
Bit 8 = SY 227 (when Bit 8 = 0: SY 127).

(ix) In the HV IN polarity selection the read lines mean the following:
Read line = 0: negative and positive polarity.
Read line = 1: positive polarity.
Read line = 2: negative polarity.

(x) In the Zero Current Set command the data on the Write Line must equal 1.

4. *RESET*

RESET is made via a F9 or Z, which cause a Power-ON cycle in the C 139 CAMAC Interface.
After a RESET Command has been issued, a wait time of at least 300 msec has to be introduced before any other CAMAC function can be successfully performed on the system.

5. *Q-RESPONSE*

A Q-response is given to each CAMAC function performed on the Interface.
A Q=0 response means that the C 139 is busy, and that the function has been rejected: it has to be repeated until a Q=1 response is obtained. On the other hand, during readout, data are valid only when Q=1, and will continue to be valid until Q becomes 0.

If a single negative word is obtained in a READ VALUE operation, this is interpreted as an error code.

After each F16 or F17 function, it is wise to perform an F0 to read the relative error code (see below for a comprehensive list of the errors).

6. *ERROR CODES*

ERROR CODES FOR BOTH SYSTEMS:

0	successful operation
-1	invalid F 17 (re-initialises from SELECT TARGET)
-2	attempt to START READ OUT without previous SELECT TARGET
-3	attempt to WRITE DATA without previous SELECT TARGET
-32	channel selected non-existent
-33	attempt to write a too small a parameter value
-34	attempt to write a too large a parameter value
-48	selection of non implemented function
-256	selection of non-existent Crate

ERROR CODES VALID FOR THE SY 127 SYSTEM:

-4	attempt to change a Status bit different from ON / OFF
-5	attempt to write a Read-only parameter (Subaddress > 8)
-6	attempt to assign a Channel to a non-existent Group (the Groups are represented by the first 8 bits of the Write lines, and a bit higher than 7 has been used)
-7	attempt to write the Total Width Time of the Streamer-tubes-conditioning
-8	attempt to Start, Stop, Pause the Streamer-tubes-conditioning process. (this can only be done from a terminal directly connected to the system)
-9	during Absolute Group Selection, attempt to write with A>7
-10	attempt to use a bit different from 0 when writing a Status
-11	during Relative Group Selection, attempt to write with A>6.
-12	error in setting protection bit

ERROR CODES VALID FOR THE SY 227 SYSTEM:

-35	attempt to change ON/OFF HV different from bit 0
-36	attempt to switch -on with HV IN present
-37	attempt to change Pulse Test EN/DIS different from bit 0
-38	attempt to change Password EN/DIS different from bit 0

NOTE.

Error codes different from those referred to the selected system are not significant.